BIKINI

Print file size for **BIKINI TOP**, **BIKINI BOTTOM FRONT** and **BACK**

33 × **32”**
width height

RESOLUTION
Graphics should be **at least 150 dpi**

COLOR
All colors should be in **RGB**.

AVOID TRANSPARENT BACKGROUNDS
Use white color for background instead

FONTS
All fonts in the print files should be converted to outlines so you don’t have to send over the font files.

FILE FORMAT
Please submit your files in **.PNG** or **.PSD** format

PLACEMENT
Exact placement is **not possible**. Making a seamless image that goes from front to back is not possible. We cannot guarantee exact graphic and text placement nor alignment on seams.







TECHNICAL DRAWING

Bikini can be worn on **both sides**, stretchy piping available in black or white.
Bikini strap lenght:
Top- 20” (51 cm)
Bottom- 16” (41 cm)



Instructions on how to prepare a printfile

Ai

1. **CREATE** 1 new document sized to **Width: 33” x Height: 32”**
   - Make sure Raster effects are set to **150dpi** or higher
   - Make sure the color space is set to **RGB**
2. **PLACE** raster grahics or create / copy & paste vector graphics within maximum graphic size area.
   Pay attention to graphics resolution (see requirements above)

3. **EMBED** raster graphics

4. **CREATE OUTLINES** of all vector fonts
   Select text first

5. **EXPORT**
   1. Choose “File” - “Export”
   2. Rename your file
   3. Choose either **.png** or **.jpg** as the file format
   4. Click the **“Use Artboards”** checkbox
   5. Click “Export”
   6. Make sure your **resolution is 150dpi** or higher
   7. Make sure the color space is set to **RGB**
   8. Click **“OK”** to save file

Ps

1. **OPEN** The Printful backpack templates or **CREATE** new documents
2. Create or copy / paste graphics within maximum graphic size area.
   Pay attention to graphics resolution.
3. **CONVERT TO SHAPE** all vector fonts
   Select text layer first

4. **SAVE**
   1. Turn off the guides by using the eye icon tool
   2. Choose File - Save As and Rename your file
   3. Save as .jpg