BEACH BAG

PRINT FILE SIZE FOR BEACH BAG

21" × 37"
width height

Fill the entire area for full bleed

SAFE PRINTING AREA

Keep important text or graphics inside this area



PRINT FILE SIZE FOR INSIDE POCKET

10" × 17,5"
width height

Fill the entire area for full bleed

SAFE PRINTING AREA

Keep important text or graphics inside this area



Pocket is sewn **inside** beach bags top seam

RESOLUTION

Graphics should be **at least 150 dpi**

COLOR

All colors should be in **RGB**.

AVOID TRANSPARENT BACKGROUNDS

Use white color for background instead

FONTS

All fonts in the print files should be converted to outlines so you don't have to send over the font files.

FILE FORMAT

Please submit your files in **.JPG**, **.PNG** or **.PSD** format

Instructions on how to prepare a print file

1. **CREATE** 2 new documents sized to :
   Width: 21" x Height: 37" and
   Width: 10" x Height: 17,5"
2. **PLACE** raster grahics or create / copy & paste vector graphics within maximum graphic size area.

   Pay attention to graphics resolution.

3. **EMBED** raster graphics

4. **CREATE OUTLINES** of all vector fonts

   Select text first

5. **EXPORT**
   1. Choose "File" - "Export"
   2. Rename your file
   3. Choose either **.jpg** or **.png** as the file format
   4. Click the **"Use Artboards"** checkbox
   5. Click "Export"
   6. Make sure your **resolution is 150dpi** or higher
   7. Make sure the color space is set to **RGB**
   8. Click **"OK"** to save file

1. **OPEN** The Printful template or **CREATE** new document
2. Create or copy / paste graphics within maximum graphic size area.

   Pay attention to graphics resolution.
3. **CONVERT TO SHAPE** all vector fonts

   Select text layer first

4. **SAVE**
   1. Turn off the guides by using the eye icon tool
   2. Choose File - Save As and Rename your file
   3. Save as **.jpg** or **.png**